



# PRODUCT INSTALLATION GUIDE

## M16-20 SERIES



Scan the code to watch the  
product installation video



Company: Shenzhen Sihoo Intelligent Home Co., Limited

Company Address: Building #A, Yuyuan Industrial Park, Baoan District,  
Shenzhen City, Guangdong Province, China

Manufacturer: FoShan Kezhimei Home Co., Limited

Manufacturer address: Jiujiang Town, Nanhai District, Foshan City,  
Guangdong Province, China.

Company Website: [www.sihoo.com/en/](http://www.sihoo.com/en/)

60\*66\*110.5(131.5)CM

[www.sihoo.com/en/](http://www.sihoo.com/en/)



## Assembly Introduction


(The size will be according to regular measurements)

<b>1</b> 	<b>2</b> 	<b>3</b> 
Put the castor into the base by pressing.	Put the gas lift into the middle hole of the base.	Code1, use 2 pcs M6*35 screws and 2pcs small shims. Code2, use 4 pcs M6*50 screws and 4pcs small shims fix the armrest to the seat cushion.
<b>4</b> 	<b>5</b> 	<b>6</b> 
Fix the mechanism to the seat cushion with 4 pcs small shim and 4 pcs (M6*20) screws.	Fix the back plate to the seat cushion with 3 pcs big shim and 3 pcs (M8*45)screws.	Put the mechanism into the gaslift.
<b>7</b> (Without headrest version don't have this step) 	Insert the headrest into the slot. Then the chair installation is completed.	



## Functions

(The size will be according to regular practice)



## Installation Instruction

- Before installation, please read all the safety instructions below (drawings) carefully and master the installation steps and methods.
  - Counting the parts is complete or not, if there is any breakage.
  - To avoid injury, it is recommended that you wear gloves during installation.
  - Please choose a spacious and clean flat floor for installation, and then lay the paper sleeves on the ground, to avoid collision between components and the ground.
  - To avoid using the wrong screws, please fix all the screws before tightening them.
  - Please note that once the gas lift is installed, it is difficult to remove.
- If you need to disassemble the chair, such as moving, please gently tap the head of the gas lift with a rubber-tipped hammer several times, and then remove the base. After that, continue to gently tap the base, using the principle of vibration to make the gas lift fall off. Please be careful not to get hurt as tools are needed to do this.
- (Damage and accidents caused by this operation do not fall within the scope of product warranty, please careful operation.)

## Precautions For Use

- Please note that this product is designed for one person, one chair is for one person only.
- For the use of product features, please follow the instructions in the product features display.
- Make sure all screws and components are locked tightly before using this product and check it at least once every 3 months.
- Please use on the flat floor, avoid wet or fireworks places, avoid long time direct sunlight.
- Don't use sharp or hooked objects to scrape the chair and do not get it close to the fire.
- Not allowing the child under 5 years old to sit on the chair alone.
- Please don't sit on the armrest, stand on the chair or use it as a ladder or footsteps, in case cause some danger.
- To avoid any harm to your fingers don't insert them into the mechanism while sitting.
- For your safety, no disassembly to the gas lift is allowed.



## Parts List

(The size will be according to regular measurements; One more as a backup)

Castors: 5pcs	Chair Base: 1 pc	Gas lift: 1 pc	Armrest: 1pair
Seat cushion: 1 pc	Mechanism: 1 pc	Headrest: 1 pc (Without headrest version no headrest here)	Backrest: 1 pc
Hex wrench: 1 pc	Small shim: 10+1 pcs	Big shim: 3+1 pcs	Back plate screw (M8*45): 3+1 pcs
Armrest Screw (M6*35): 2+1 pcs	Armrest Screw (M6*50): 4+1 pcs	Mechanism screw (M6*20): 4+1 pcs	

Note: Before installation, pls classify the screw, measure the screw lengths to easy assemble.